

MOUNTING LOCATION:

Right side of radio J R

TOOLS REQUIRED:

Hook tool, Dash Tool

9/32" Socket Driver

Clean Shop Cloth

HARDWARE INCLUDED:

(2)A #8x9/16" Needle Pt. Screw

CELL PHONE & MEDIA MOUNT

INSTALLATION INSTRUCTIONS

PART#:75107-307

MFG: FORD/LINCOLN/CHEVY/PONTIAC

This Page: MODELS & YEARS:

FORD F-150 2004-08(ex:Heritage)

F-150 Lightning 2004, Expedition 07-10

LINCOLN-Mark LT 2006-08(Pg.1)

Navigator 07-13 (Only Pg.2)

CHEVY- Aveo 07-09 (4-Door Only)

PONTIAC-Wave 07-09 (4-Dr), G3 2009 (Pg.3)

**** ADVISEMENT ****

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

NOTE: Instructions apply to both all models, with or without console.

STEP#1: For F-150 & Mark LT, Open the cup holder or tray below the lighter / power outlet. **For Expedition 2007,** Insert hook tool into the side of the cover below the climate control to release (4) clips. Set this cover aside..

STEP #2: With hook tool insert it between the bezel and dash below the lighter / power outlet, to the right or left side of the center bezel to release one clip on each side. Lift bezel out from the bottom to allow hook tool to fit in behind the bezel about the center of the sides of the radio. Pull to release (2) clips, (1) on each side. Insert hook tool into the upper part of the bezel between the bezel and upper tray. Pull on right or left side to release (2) clips, (1) on each side. Pull bezel out far enough and to the side to get at the screws that holds the right side of the radio in place. Use Clean Shop Cloth to protect surfaces as necessary.

STEP#3: With 9/32" socket driver remove the (2) screws that hold the right side of the radio in place. Angle in and place InDash by PanaVise Mount over the (2) screw holes. Reinstall the (2) screws.

STEP#4: Replace the bezel in reverse order.

INSTALLATION IS COMPLETE. ENJOY YOUR NEW INDASH by PANAVISE MOUNT



Expedition Cover Removal



F-150 With Ashtray



F-150 Without Console



Finished Install Picture



Some Clip Locations Shown



02-20-13

INDASH by PANAVISE®

I-75107-307

Page 2 of 3

MOUNTING LOCATION:

Right side of radio J R

TOOLS REQUIRED:

Hook tool

9/32" socket driver

Phillips Screwdriver

Clean shop cloth

HARDWARE INCLUDED:

(2)A #8x9/16' Needle Pt. Screw

CELL PHONE & MEDIA MOUNT

INSTALLATION INSTRUCTIONS

PART#:75107-307

MFG:FORD/LINCOLN/CHEVY/PONTIAC

This Page: MODELS & YEARS:

Navigator 07-13 (Only Pg.2)

Other Pages:

CHEVY-Aveo 07-09 (4-Door Only)

PONTIAC-Wave 07-09 (4-Dr), G3 2009 (Pg.3)

FORD F-150 2004-08 (ex:Heritage)

F-150 Lightning 2004, Expedition 07-10

LINCOLN-Mark LT 2006-08 (Pg.1)

** ADVISEMENT **

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

Start Here for Lincoln Navigator:

STEP#1: Remove the trim ring around the shifter. There are (4) plastic ribbed clips, (2) at the back, and (2) at the front sides of the ring. Open the console door. With hook/dash tool remove the console top starting from the back by the console. There are (6) total clips. Starting with (2) at the back and (2) more along the side, and finally (2) that are in a horizontal position at the front of the console cover.

STEP#2: Lift bezel out from the bottom to allow hook tool to fit in behind the bezel about the center of the sides of the radio. Pull to release (2) clips, (1) on each side. Insert hook tool into the upper part of the bezel between the bezel and upper tray. Pull on right or left side to release (2) clips, (1) on each side. Pull bezel out far enough and to the side to get at the right side of the radio cavity. Use Clean Shop Cloth to protect surfaces as necessary.

STEP#3: Place the InDash by PanaVise Mount on the flat area to the right of where the switches are on the radio and climate control bezel. With Phillips Screwdriver install the (2) supplied screws.

STEP#4: Replace the bezel and console top in reverse order.

INSTALLATION IS COMPLETE. ENJOY YOUR NEW INDASH by PANAVISE MOUNT



InDash Final Install Picture
Showing Location



Trim Ring Removal



Screws Below Ashtray



InDash Mounted
Showing Location



02-20-13

INDASH by PANAVISE®

I-75107-307

Page 3 of 3

MOUNTING LOCATION:

Right Side of Radio Cavity KR

TOOLS REQUIRED:

Hook tool, Dash Tool

9/32" Socket Driver

Clean Shop Cloth

HARDWARE INCLUDED:

(2) A #8x9/16" Needle Pt. Screw

CELL PHONE & MEDIA MOUNT

INSTALLATION INSTRUCTIONS

PART#: 75107-307

MFG: FORD/LINCOLN/CHEVY/PONTIAC

This Page: MODELS & YEARS:

CHEVY- Aveo 07-09 (4-Door Only)

PONTIAC-Wave 07-09 (4-Dr), G3 2009 (Pg.3)

Other Pages:

FORD F-150 2004-08 (ex: Heritage)

F-150 Lightning 2004, Expedition 07-10

LINCOLN-Mark LT 2006-08 (Pg.1)

Navigator 07-13 (Only Pg.2)

** ADVISEMENT **

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

For Chevy Aveo, Pontiac Wave, & G3 (4-Dr) Start Here:

STEP#1: Insert Hook Tool into the outside upper Right of Left side of the radio bezel. Pull to release (1) clip each side. Continue to release the U-shaped bezel, there are a total of (6) clips.

STEP#2: With Phillips screwdriver remove (2) screws to the right of the radio. Place the InDash by PanaVise Mount over the holes and reinstall the screws.

STEP#3: Replace the bezel.

INSTALLATION IS COMPLETE. ENJOY YOUR NEW INDASH by PANAVISE MOUNT



Mount Installed Showing Location



Final Installation Picture



02-20-13